

Warranty & Safety

Radio Controlled Helicopters of this size are not Toys!

Please read before use.

Radio controlled helicopters use various high tech electronic technologies and products. Improper use of these products can result in serious injury, or even death. Please read this manual carefully before flying the Rush 750 $_{\text{TM}}$. Make sure to be conscious of your own safety and the safety of others.

Neither AleeS Inc nor its affiliated groups or sellers have any control over the assembly, maintenance, and use of this product. Therefore, no responsibility can be traced back to the manufacturer. By assembling and flying this product, you hereby agree to release AleeS Inc., its Distributors, Dealers, and Affiliates from any responsibility or liability arising from the use of this product.

The user/purchaser is responsible for common knowledge and observance of one's own safety and the safety of others that may be affected by the use of the product be they a participant or spectator. This radio controlled helicopter is intended for use only by those with experience flying radio controlled helicopters at a legal flying field. After the sale of this product, we cannot maintain any control over its operation or usage. We recommend that you obtain assistance from an experienced pilot before attempting to fly our products and to help verify proper assembly, setup, and flight of your model for the first time. This AleeS TM helicopter is a consumer item that requires a certain degree of skill to operate. Any damage or dissatisfaction as a result of accidents or modifications are not covered by any warranty and cannot be returned for repair or replacement.

Safety notes:

You can lose control over the helicopter at any given moment for a number of reasons, NEVER fly over or near other people.

Choose a legal flying field

- Verify air field to have ample space, flat, and smooth ground.
- Clear airfield from debris and obstacles.

Do not operate:

- If model has been in contact with rain, moisture, or contaminants.
- If model has been in contact with fire or high heat plastics are very susceptible to damage or deformation due to heat.
- In crowed areas.
- Near homes, schools, or hospitals.
- Near roads, railways, or power lines.
- Near another radio controlled unit that uses same frequency.
- Do not allow children to operate.
- If tired, sick, or under the influence of drugs or alcohol.
- If beginner or individual (s) planning to operate a borrowed helicopter without being familiar with model or safety instructions.

Inspect All Parts

- Before each flight, check for damaged parts and verify all parts operate normally with all functions in order.
- Adjust the positioning of movable parts and check that all nuts, bolts, screws are fastened correctly in accordance to this instruction manual.
- Verify all parts are installed correctly.
- Verify that there are no abnormalities that would adversely affect the flight of the helicopter.
- Verify all batteries on board helicopter and transmitter are to a sufficient level of charge.
- Exchange or repair damaged or worn parts using only parts shown in this instruction manual, or via the online catalog.
- Verify there is no introduction or exposure to water or moisture in any form.

During operation of helicopter:

- Maintain safe distances from aircraft and rotating main/tail rotor blades.
- Always be aware of your surroundings and be conscious of your actions.
- Never leave your model unattended.
- Maintain eye contact during all aspects of flight.
- Maximum main rotor speed of 2000 RPM's for 690-710mm rotor blades, and 1800 RPM's for 720mm+ rotor blades, or maximum specified speed by the rotor blade manufacturer. Failure to maintain these speeds could result in catastrophic failure of either the aircraft and/or rotor blades which could result in injury or even death!

Mechanical Features

FEATURES & BENEFITS

Chassis and Drive System:

- 112T CNC helical main gear modulus 1;
- 105T CNC auto-rotation gear modulus 1;
- 23T CNC counter gear modulus 1;
- 24T bevel gears modulus 1;
- AleeS all-new, industry's first "TDD" Drive System (patent pending; more details to come);
- Field replaceable bevel and counter gears;
- Dual ball bearing supported one-way hub assembly with sprag style clutch bearing;
- Triple main shaft bearing support;
- Bridged top bearing block for superior drive system rigidity;
- Motor shaft end bearing block;
- Large open saddle style battery pockets for up to 7s packs with room to spare;
- Ample space for modern electronics placement, ventilation and serviceability;
- Protective flybarless gyro mounting compartment;
- Direct servo to swash linkage for reduced parts count;
- Easy servo install/removal design;
- Sleek carbon fiber landing skid standard; and
- Canopy pin break away system.

Head System:

- Robust triple radial bearing main blade grips
- 10mm Super Duty Spindle shaft
- 1 piece flap Hard 3D dampers
- Compact center hub
- AleeS "2SIC" innovative rotor head design (patent pending) combined phasing/pitch/cyclic control levers with dual step bearing placement for increased operational precision and low servo loading
- Heavy duty plastic ball links for today's high-power demands
- Compact swash plate with maintenance friendly design
- Stainless steel linkage balls for strength and improved wear resistance
- Turnbuckle style swash linkage rods; and
- Turnbuckle style pitch linkage rods

Tail System:


- Ultra rigid aluminum tail boom;
- Ultra rigid torque tube shaft with quad ball bearing support;
- Split ring tail control rod guides for easy install/removal;
- Compact tail hub and gear box;
- Dual supported pitch mechanics;
- Anti-twist tail case w/ safety locking pin screw; and
- Dual radial and thrusted tail blade grips.

Canopy:


- AleeS all-new "Legend II" canopy with superb aerodynamic characteristics;
- Air-brushed by Canomod.

ASSEMBLED SPECIFICATION:

- Length: 1185mm (without Canopy)
- Height: 398mm
- Width: 185mm
- Air Frame only with canopy weight: 1.8kg
- Approximate Ready to fly weight: 5.0kg
- Main Rotor Diameter w/ 710mm blades : 1608mm
- Tail Rotor w/115mm blades: 296mm
- Torque Tube drive gear ratio: 4.57:1




Flybarless Head




Flybarless Head

Bag 2




Thrust Bearing 10x18x5.5mm (F10-18M)



Battery Tray

Bag 3 and 6




Use thread lock compound on all screws noted by Color:
Blue = Medium - Red = Strong


Set Screw M3 x 12mm

....x7

Tray Assemblies

Bag 3 and 6








Use thread lock compound on all screws noted by Color:
Blue = Medium - Red = Strong




Bearing **Assemblies**












Boom Mount Assembly

Bag 4











Boom Mount Assembly

Bag 4 and 6











Bag 5 and 6




Use thread lock compound on all screws noted by Color:
Blue = Medium - Red = Strong

Cap Screw M3 x 8mm
.....x3
Cap Screw M3 x 10mm





Bag 5 and 6


Previously assembled items not shown for clarity



Use thread lock compound on all screws noted by Color:
Blue = Medium - Red = Strong








Frame Assembly Bag 5 Servo Mount [Part # 200-0015] ...QTY 4 Install to Exteriour 001 Phillips Special Screw 0 M2 x 6mm (Part # PSS2X6) ...QTY 4 CF Left Frame Matte Finish (Part # 202-0042) ...QTY 1 Use thread lock compound on all screws noted by Color: Blue = Medium - Red = Strong Special Phillips Screwx 4

Bag 5

Previously assembled items not shown for clarity




Use thread lock compound on all screws noted by Color:
Blue = Medium - Red = Strong

Cap Screw M3 x 6mm

Bag 5


Previously assembled items not shown for clarity





Use thread lock compound on all screws noted by Color:
Blue = Medium - Red = Strong


Cap Screw M3 x 6mm
.....x 2
Cap Screw M3 x 8mm
.....x 9

Bag 5 and 6










Bag 5 and 6

Previously assembled items not shown for clarity

Button Head Screw M3 x 6mm (Part # BHS3X6) ...QTY 4




Use thread lock compound on all screws noted by Color:
Blue = Medium - Red = Strong


Button Head Screw M3 x 6mm
.....x4


CF Skid Assembly

Bag 6 and 7




Frame Assembly Previously assembled items not shown for clarity M3 Insert (Part # 201-0031) ...QTY 4 **9** Cap Screw M3 x 8mm (Part # CS3X8) ...QTY 4 Use thread lock compound on all screws noted by Color: Blue = Medium - Red = Strong Cap Screw M3 x 8mmx 4 Copyright © 2014 AleeS Inc. All rights reserved.







Head Installation


Bag 8






Button Head Screw M3 x 10mm (Part # BHS3X10) ... QTY 2







Tail System


Bag 9






Tail Linkage Rod Self Tapping Cap Screw M2x8mm Bag 10 Ball Link (Part # 100-0009) ... QTY 2 Rod Guide (Part # 300-0016) ... QTY 4 * * *Tail Linkage Rod Measurement* * * 767 mm (Approx.) Self Tapping Screw M2 x 8mm [Part # STHSS2x8] ... QTY 4 Tail Linkage Rod (Part # 300-0015) ... QTY 1 Partially Install Self-Tapping Screws once in place after install onto Boom then tighten until Rod guide will no longer move (do not over tighten) Use thread lock compound on all screws noted by Color: Blue = Medium - Red = Strong










Boom Assembly Installation


! Install boom assembly until boom opening is completely seated in front boom mount. Once seated align logo on boom and Install (2) Pin screws as shown in Rear Boom mount. Now tighten all (2) M3 pinch clamp screws in rear mount

Install plastic ball link on tail servo linkage ball upon above noted steps












Electronics Placement





Mechanical Setup

At zero degree of pitch levers on center hub should be in noted position to achieve 23 (+) Pos and (-) Neg degree of pitch range



At 90 degree with pitch arm. Tail system will have 8 degrees of counter torque pitch in tail blades. This is mechanically built in and cannot be removed. Set counter torque with end point limit in Gyro to be bind free. (Pitch slider assembly moves towards tail case). Match limit number for opposing side. Extra travel room will be available but is not needed.

